

Fare Types	Cost	Operators Pushing
Full cash	\$2.00	Left arrow 1 (or * + 1)
Reduced cash (senior/disabled/medicare/income)	\$1.00	Left arrow 2 (or * + 2)
Youth cash	\$1.50	Left arrow 3 (or * + 3)
31-day full pass	\$50.00	nothing (swipeable)
31-day reduced pass (senior/disabled/medicare/income)	\$35.00	nothing (swipeable)
31-day youth pass	\$40.00	nothing (swipeable)
Annual pass	\$300.00	nothing (tap-tap bullseye)
10-ride full card	\$18.00	nothing (insert)
10-ride reduced card (senior/disabled/medicare/income)	\$9.00	nothing (insert)
10-ride youth card	\$15.00	nothing (insert)
Short Fare/Passenger does not have all the fare	Partial or No Fare	Left arrow 4 (or * + 4)
Ride-through	No Fare	Right arrow 2
Metro employee pass	No Fare	Right arrow 3 (or * + 7)
Metro dependent pass	No Fare	Right arrow 3 (or * + 7)
Metro retiree pass	No Fare	Right arrow 3 (or * + 7)
Children under age 5	No Fare	Right arrow 3 (or * + 7)
Transit educator pass	No Fare	Right arrow 3 (or * + 7)
Jurors Ride Free program	No Fare	Right arrow 3 (or * + 7)
Free ride card (paper business card)	No Fare	Right arrow 3 (or * + 7)
Washburn University/Tech Students	No Fare	nothing (swipeable)
Washburn University/Tech Students FAILS	No Fare	Button A
Washburn Tech GED/ESL Students	No Fare	Button A
Kids Ride Free (MAY 15-AUG 15 UNLESS NOTED OTHERWISE)	No Fare	Button D
Media Fail (magnetic stripe or tap cards) except: * Use Button A for WU/WU Tech fails *	No Fare	Right arrow 1 (or * + 5)
Issue 24-hour reduced pass	Issue - \$2.00	Button 2
Issue 24-hour youth pass	Issue - \$3.00	Button 3
Issue 24-hour full pass	Issue - \$4.00	Button 4
Bikes	Count only	Button 5 (or * + 6)
USD #501 High School Students	No Fare	Button 6
Field trip group (school, camp, church, etc)	No Fare	Button 9
Issue 24-hour full pass (back-up to 4 button)	Issue - \$4.00	Button 7
Shuttles & Events	No Fare	Button 8
MOD passengers	Count only	* + 8
(Currently Unused)		* + 9
Issue a change card - NOT AVAILABLE ON CENTSABILL		Right arrow 4
Clear a stuck card from the farebox		Green button + C

NOTE: CentsABill units use the * button + a number button since there is no OCU or soft keys.